

Introduction to Physical Layer



**Computer Networks
Term A15**


Physical Layer Outline

- **Definitions**
- **Multiplexing**
- **Transmission Media**
- **End System Choices**
- **Residential Configurations**

Physical Layer Definitions

- The time required to transmit a character depends on both the **encoding method** and the **signaling speed** (i.e., the **modulation rate** - the number of times/sec the signal changes its voltage).
- **baud (D)** - the number of changes per second.
- **bandwidth (H)** - the range of frequencies that is passed by a channel. The transmitted signal is constrained by the transmitter and the nature of the transmission medium in cycles/sec (hertz).
- **channel capacity (C)** - the rate at which data can be transmitted over a given channel under given conditions. {This is also referred to as data rate (R).}

Modulation Rate



modulation rate
is doubled

Figure 5.5 A Stream of Binary Ones at 1 Mbps

DCC 6th Ed.
Stallings

Analog and Digital Signaling

signals:: electric or electromagnetic encoding of data.

signaling:: is the act of propagating the signal along a suitable medium.

Analog signal - a **continuously varying** electromagnetic wave that may be propagated over a variety of medium depending on the spectrum (e.g., wire, twisted pair, coaxial cable, fiber optic cable and atmosphere or space propagation).

Analog and Digital Signaling

digital signal – a sequence of **voltage pulses** that may be transmitted over a wire medium.

Note – analog signals to represent analog data and digital signals to represent digital data are **not** the only possibilities.

There is where **modems** and **codecs** come into the picture.

Analog vs Digital (three contexts)

Analog data	Two alternatives: (1) signal occupies the same spectrum as the analog data; (2) analog data are encoded to occupy a different portion of spectrum.	Analog data are encoded using a codec to produce a digital bit stream. codec
Digital data	Digital data are encoded using a modem to produce analog signal. modem	Two alternatives: (1) signal consists of two voltage levels to represent the two binary values; (2) digital data are encoded to produce a digital signal with desired properties.

(a) Data and signals


	Analog transmission	Digital transmission
Analog signal	Is propagated through amplifiers; same treatment whether signal is used to represent analog data or digital data.	Assumes that the analog signal represents digital data. Signal is propagated through repeaters; at each repeater, digital data are recovered from inbound signal and used to generate a new analog outbound signal.
Digital signal	Not used	Digital signal represents a stream of 1s and 0s, which may represent digital data or may be an encoding of analog data. Signal is propagated through repeaters; at each repeater, stream of 1s and 0s is recovered from inbound signal and used to generate a new digital outbound signal.

(b) Treatment of signals

**DCC 6th Ed.
Stallings**

Multiplexing

Multiplexing {general definition} ::
Sharing a resource over time.



Leon-Garcia & Widjaja:
Communication Networks


Frequency Division Multiplexing (FDM) vs Time Division Multiplexing (TDM)

Example:


4 users



FDM



TDM



K & R

Frequency Division Multiplexing




Figure 2-31. (a) The original bandwidths. (b) The bandwidths raised in frequency. (c) The multiplexed channel.

Tanenbaum

T1 - TDM Link

TDM:: each host gets a **fixed** slot in revolving TDM frame





Figure 2-33. T1 Carrier (1.544Mbps)

Tanenbaum

Concentrator [Statistical Multiplexing]




2.10

FIGURE

In statistical multiplexing, the multiplexer visits the incoming channel buffers in some order. The multiplexer empties a buffer before moving to the next one. The buffer contents are tagged to indicate their incoming channel. An idle channel does not waste transmission time.

Packet Switching: Statistical Multiplexing



Sequence of A & B packets does **NOT** have fixed pattern, bandwidth shared on demand → **statistical multiplexing**.

Wavelength Division Multiplexing




Figure 2-32.

Tanenbaum

Physical Media: Twisted Pair

- **Bit:** propagates between transmitter/receiver pairs.
- **physical link:** what lies between transmitter & receiver.
- **guided media:**
 - signals propagate in solid media: copper, fiber, coax.
- **unguided media:**
 - signals propagate freely, e.g., radio.

Unshielded Twisted Pair (UTP)

- two insulated copper wires
 - Category 3: traditional phone wires, 10 Mbps Ethernet
 - Category 5 : 100Mbps Ethernet



Category 5e is now standard!!

EIA/TIA 568 and ISO/IEC 11801 Wiring Grades

Grade 1 - Unshielded Untwisted wiring.

Commonly called inside wire by the Telco community.

Grade 2 - Unshielded twisted pair (UTP) derived from IBM Type 3 spec.

Category 3 - Unshielded twisted pair with 100 ohm impedance and electrical characteristics supporting transmission at frequencies up to **16 MHz**. May be used with 10Base-T, 100Base-T4, and 100Base-T2 Ethernet. **(Obsolete)**

Category 4 - Unshielded twisted pair with 100 ohm impedance and electrical characteristics supporting transmission at frequencies up to **20 MHz**. May be used with 10Base-T, 100Base-T4, and 100Base-T2 Ethernet. **(Obsolete)**

Category 5 - Unshielded twisted pair with 100 ohm impedance and electrical characteristics supporting transmission at frequencies up to **100 MHz**. May be used with 10Base-T, 100Base-T4, 100Base-T2, and 100Base-TX Ethernet. May support 1000Base-T, but cable should be tested. **(Superseded by Cat5e)**

"Modern" Twisted Pair

Table 4.2 Twisted Pair Categories and Classes

	Category 5e Class D	Category 6 Class E	Category 6A Class E_A	Category 7 Class F	Category 7A Class F_A
Bandwidth	100 MHz	250 MHz	500 MHz	600 MHz	1,000 MHz
Cable Type	UTP	UTP/FTP	UTP/FTP	S/FTP	S/FTP
Insertion loss (dB)	24	21.3	20.9	20.8	20.3
NEXT loss (dB)	30.1	39.9	39.9	62.9	65
ACR (dB)	6.1	18.6	19	42.1	44.1

UTP = Unshielded twisted pair

FTP = Foil twisted pair


S/FTP = Shielded/foil twisted pair

**DCC 9th Ed.
Stallings**

Physical Media: Coaxial Cable and Optical Fiber

Coaxial cable:

- two concentric copper conductors
- bidirectional
- baseband:
 - single channel on cable
 - legacy Ethernet
- broadband:
 - multiple channels on cable
 - HFC



Fiber optic cable:

- glass fiber carrying light pulses, each pulse a bit
- high-speed operation:
 - point-to-point transmission (e.g., 10's-100's Gps)
- low error rate: repeaters spaced far apart ; immune to electromagnetic noise.




Physical Media: Radio Signals

- signal carried in electromagnetic spectrum.
- no physical “wire”
- bidirectional
- propagation environment effects:
 - reflection
 - obstruction by objects
 - interference

Radio link types:


- **terrestrial microwave**
 - e.g. up to 45 Mbps channels
- **LAN** (e.g., Wifi)
 - 11Mbps, 54 Mbps, 200Mbps
- **wide-area** (e.g., cellular)
 - 4G cellular: ~ 100 Mbps
- **satellite**
 - Kbps to 45Mbps channel (or multiple smaller channels)
 - 270 msec end-end delay
 - geosynchronous versus low altitude

Dial-up Modem



- Uses existing telephony infrastructure.
- Home is connected to **central office (analog signals)**.
- up to 56Kbps direct access to router (often less)
- Can't surf and phone at same time: not **"always on"**.

Digital Subscriber Line (ADSL)




- Uses existing telephone infrastructure.
- up to 1 Mbps upstream (today typically < 256 kbps)
- up to 8 Mbps downstream (today typically < 1 Mbps)
- dedicated physical line to telephone central office

Comparison of xDSL Alternatives

	ADSL	HDSL	SDSL	VDSL
Data rate	1.5 to 9 Mbps downstream 16 to 640 kbps upstream	1.544 or 2.048 Mbps	1.544 or 2.048 Mbps	13 to 52 Mbps downstream 1.5 to 2.3 Mbps upstream
Mode	Asymmetric	Symmetric	Symmetric	Asymmetric
Copper pairs	1	2	1	1
Range (24-gauge UTP)	3.7 to 5.5 km	3.7 km	3.0 km	1.4 km
Signaling	Analog	Digital	Digital	Analog
Line code	CAP/DMT	2B1Q	2B1Q	DMT
Frequency	1 to 5 MHz	196 kHz	196 kHz	≥ 10 MHz
Bits/cycle	Varies	4	4	Varies

DCC 9th Ed.
Stallings

VDSL



Residential Access: Cable Modems

- Does not use telephone infrastructure
 - Instead uses cable TV infrastructure.
- **HFC: hybrid fiber coax**
 - asymmetric: up to 40Mbps downstream, 6 Mbps upstream
- **network** of cable and fiber attaches homes to ISP router:
 - homes **share access** to router
 - unlike DSL, which has **dedicated access**.

Residential Access: Cable Modems






Diagram: <http://www.cabledatacomnews.com/cmhc/diagram.html>

Cable Network Architecture: Overview


Typically 500 to 5,000 homes




Cable Network Architecture: Overview



Cable Network Architecture: Overview



Cable Network Architecture: Overview



DOCSIS (Data-Over-Cable Service Interface Specification)

Cisco DOCSIS 3.0 Solution





Figure 4. M-CMTS and DOCSIS 3.0 Downstream Channel Bonding


Cable Access Networks



- ❖ FDM over upstream, downstream frequency channels
- ❖ **multiple** 40Mbps downstream (broadcast) channels (6MHz)
 - single CMTS transmits into channels and received by **all** modem receivers.

K & R


DOCSIS Cable Access Networks



- ❖ multiple 30 Mbps upstream channels (6.4MHz)
- ❖ TDM-like upstream mini-slots

K & R

Fiber to the Home





- Optical links from central office to the home
- Two competing optical technologies:
 - Passive Optical network (PON) ← Verizon FIOS
 - Active Optical Network (AON)
- Higher Internet rates. Fiber also carries television and phone services.

AON Active Optical Network

- Uses electrical powered switches
- More range
- Less reliable

PON Passive Optical Network


- Optical splitters do not need electrical power.
- Hard to isolate failure
- Transmission speed may be slower during peak hours.



Key: **A** - Data or voice for a single customer. **V** - Video for multiple customers.

Wikipedia


Ethernet Internet Access



- Typically used in companies, universities, etc
- 10 Mbs, 100Mbps, 1Gbps, 10Gbps Ethernet
- Today, end systems typically connect into Ethernet switch.

Wireless Access Networks


- Shared **wireless** access network connects end system to router
 - via base station aka “access point”.
- **Wireless LANs:**
 - 802.11b/g/n (WiFi): 11, 54, 200 Mbps
- **Wider-area Wireless Access**
 - provided by telco operator
 - ~1Mbps over cellular system (EVDO, HSDPA) 3G and 4G LTE
 - next up (?): WiMAX (10's Mbps) over wide area



Residential Networks

Typical Residential Network Components:

- DSL or cable modem
- router/firewall/NAT
- Ethernet
- wireless access point (AP)



Physical Layer Summary

- Definitions (analog versus digital)
- Multiplexing (FDM, TDM, statistical)
- Transmission Media (UTP, Coax, Fiber, Radio, Satellite)
- End System Choices (Dial-Up, ADSL, Cable, Ethernet, Wireless AP, Fiber-to-the Home)
- Residential Configurations