# Point-to-Point Network Switching



Computer Networks
Term B14

# Network Switching Outline

- Circuit Switching, Message Switching,
   Packet Switching, Cell Switching
- Connection-Oriented versus
   Connectionless Protocols
- Virtual Circuit versus Datagram
   Networks
- External/Internal Subnet Abstractions



# Circuit Switching

- Seeking out and establishing a physical copper path from end-to-end [historic definition]
- · Circuit switching implies the need to first set up a dedicated, end-to-end path for the connection before the information transfer takes place.
- Once the connection is made, the only delay is propagation time.



# Circuit Switching




Figure 2-38. (a) Circuit switching. (b) Packet switching.


Tanenbaum



#### Network Core: Circuit Switching

# End-end resources reserved for "call"

- link capacity, router buffer space
- dedicated resources: no sharing
- circuit-like (guaranteed)
   performance
- call setup required






#### Store-and-Forward Networks

- Intermediate processors (IMPS, nodes, routers, gateways, switches) along the path store the incoming block of data.
- Each block is received in its entirety at the router, inspected for errors, and retransmitted along the path to the destination.

This implies buffering at the router and one transmission time per hop.




### Store-and-Forward Routers





# 'Cut Through' Routers





# Message Switching

 A store-and-forward network where the block of transfer is a complete message.

- Since messages can be quite large, this can cause:
  - buffering problems at the router.
  - high mean delay times.



# Packet Switching

 A store-and-forward network where the block of transfer is a complete packet.

- A packet is a variable length block of data with a fixed upper bound.

\*\*Using packets improves mean message delay.



# Cell Switching

53 bytes

 A network where the unit of transfer is a small, fixed-size block of data (i.e., a cell).

 ATM (Asynchronous Transfer Mode) networks use 53-byte cells.



#### Packet Switched Networks

#### Connection-Oriented Protocols

 A setup stage is used to determine the end-to-end path before a connection is established.

Data flow streams are identified by some type of connection indicator (e.g. OSI, X.25, SNA, ATM).



#### Connection-Oriented Virtual Circuits




Figure 5-45. Internetworking using concatenated virtual circuits.

Tanenbaum



#### Packet Switched Networks

#### Connectionless Protocols

- No set up is needed.
- Each packet contains information which allows the packet to be individually routed hop-by-hop through the network.
- Bifurcated and adaptive routing techniques are possible.



# Connectionless Internetworking




Figure 5-46. A connectionless internet.

Tanenbaum



### Datagram vs Virtual Circuit

#### Datagram Routing


- Each datagram packet may be individually routed.

#### Virtual Circuit Routing

- In virtual circuit, set up is required.
- All packets in a virtual circuit follow the same path through the network.



# Transmission Event Timing



DCC 6th Ed., W. Stallings, Figure 10.3





#### External

# Virtual Circuit And Datagram Operation

DCC 6<sup>th</sup> Ed., W. Stallings, Figure 10.4








#### Internal

# Virtual Circuit And Datagram Operation

DCC 6<sup>th</sup> Ed., W. Stallings, Figure 10.5





# Networking Switching Summary

- Circuit-switching and message switching are now obsolete!!
- Store-and- forward, datagram packet switching (IP routers) dominates the Internet.
- Cell switching and virtual circuits (ATM switches) still exists in ATM networks.
- The external protocol abstraction to the subnet may differ from the internal subnet view.
  - e.g. TCP is connection-oriented protocol that runs on top of a datagram IP protocol.

